

USB Computer Speaker USER MANUAL



What's in the Box



Computer Speaker x 1





USB Cable x 1

User Manual x 1

Specifications

Model: U60 Input: 5V, 500mA Size: 144 x 70 x 36mm

Power Amplifier Output: RMS 3W

Input Interface: USB

FAQ

- **Q**: Is the U60 USB Computer Speaker plug-and-play??
- A: Yes, the U60 speaker is completely plug-and-play. It requires no drivers or software installation. Simply connect the speaker to your computer's USB port, and it will automatically start working.
- **Q**: What devices are compatible with the U60 USB Computer Speaker?
- A: The U60 speaker is compatible with most devices that have a USB port, including Windows PCs, MacBooks, laptops, desktops, and other devices that support USB audio output
- Q: How is the audio powered and transmitted?
- A: The U60 speaker is powered through a USB connection, which also transmits the audio signal. No additional power supply or 3.5mm AUX cable is required.
- Q: How do I troubleshoot if there's no sound from the
- A: If you experience no sound, ensure the U60 is securely connected to the USB port. Check your computer's audio settings to make sure the U60 speaker is selected as the default output device. Also, adjust the volume using the inline controls and ensure your system volume is turned in
- **Q**: Does the U60 speaker require a separate power adapter?

A: No, the U60 is USB-powered and does not require any external power adapter. It runs directly off your computer's USB port.

After-Sale Service

This product is covered with our product and labor warranty for 12 months from the date of its original purchase.
Any questions welcome to contact us: support@mookiz.com


Scan the QR code watch the tutorial videos



https://mookiz.com/user-manual/u6



MODKIZ



Set it work on Computer

For Windows

Click the "Speaker" icon in the taskbar.
 Select"Sound Output" > click "More Volume Setting" for system sound setting.



For Mac OS

1.Click the "System Preference" icon in the taskbar. 2.Click "Sound" icon to expand the device for sound output.



3. Select "USB Speaker" as your sound "Output" and "Input" device.



4.Select "USB Speaker" as your sound "Output" and "Input" device.



3.Select "USB Speaker" as your sound "Output" and "Input" device.



4.Select "USB Speaker" as your sound "Output" and "Input" device.

