



Wearable Wireless Speaker

USER MANUAL




mookiz

What is Included



Product Diagram



Button Control

Button	Operation	Function
Music/Phone Call		
[Power]	Press and hold for 2s	On/Off
[Play/Pause]	Press × 1	Play/Pause
	Press × 1	Answer/Hang up the call
	Press and hold for 2s	Reject call
	Press × 2	Dial the last call
[Next]	Press × 1	Volume up
	Press and hold for 2s	Next track
[Previous]	Press × 1	Volume down
	Press and hold for 2s	Previous track

Bluetooth

[Power]	Press × 1	Connect/Disconnect
[Play/Pause]	Press and hold for 5s	Clear last paired device

TWS Mode

[Power]	Press × 2	TWS on/off
---------	-----------	------------

Product Parameters

Model	D70
Bluetooth Version	5.3
Bluetooth Range	40m
Frequency Response	60Hz-20KHz
SNR	65dB
Power Input	DC5V 1A
Play Time(100%/70%Volume)	>10H(100% Volume) >30H(70% Volume)
Charging Time	2H
Battery capacity	600mAh
Product Weight	60g

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement
To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm from your body.

Scan the QR code watch
the tutorial videos



<https://mookiz.com/user-manual/d70>

